

Logical Address	Display Address	DTC Code	Diagnostic Error Code Description	Detection Conditions	Inspection Area	Malfunction Part
0B	41	—	Map Disc Malfunction	When there is a read error due to disc scratches or vibration etc., and data cannot be read for a certain period of time.	Check the condition of the map disc.	(1) Faulty Map Disc (2) Faulty Navigation ECU
	42	0x9B0049	Player Malfunction	When abnormal player operation continues for a certain period of time.	Check the navigation ECU installation.	(1) Faulty Navigation ECU
	43	0x9B0049	Player High Temperature Detection	When high player temperature is detected (player ambient temperature is over 80°C).	Check the navigation ECU surrounding temperature.	(1) If the navigation ECU surrounding temperature is too high, lower the surrounding temperature. (2) Navigation ECU