



0041-2002-C-A-01-01-Service 0.022-13M-0001



BH42-79022-C-A-02-01-Service 6.522-11M9-0811

**Sensor-Position- Accelerator pedal**




**Sensor-Low pressure fuel**




C  
Sheet4




**Mirror-Door- Passenger side**



**Module-Fuel-pump driver**




**Engine control module (ECM)**





BH2-70032-C-A-04-05-Service (J22-11MY-0001)




BH41-2002-C-A-00-00-Service (022-13M-000)


**Sensor-Camshaft position-Bank 1-Intake**



**Sensor-Camshaft position-Bank 1-Outlet**




**Sensor-Camshaft position-Bank 2-Intake**




**Sensor-Camshaft position-Bank 2-Outlet**




**Sensor-Oxygen-Odd-Pre-catalyst**




**Sensor-Oxygen-Odd-Post catalyst**





**Sensor-Oxygen-Even-Pre-catalyst**



**Sensor-Oxygen-Even-Post catalyst**



**Engine control module (ECM)**



Sheet1

Sheet1